

Moxa PCI			-Li nux	
CP-102U	CP-104U	C104H/PCI	C168U	C168/PCI
CP-132U	CP-118	CP-134U		
	Li nux	FC3	2.6.17	

```

1          PCI

2          #
3 #cd /          /*
4 #cp /mnt/cdrom/<driver directory>/mxser.tgz /* mxser.tgz
5 #tar xvfz mxser.tg
          10 #nodprobe mxser /*
          /*
          11 #cd /etc/rc.d
          12 #cp /mxser/rc.mxser
          13 #vi rc.local /* rc.local ,
          /etc/rc.d/rc.mxser

```

```

1
2 #cd /moxa/mxser/utility/diag /*
3 #. /nsdiag
4 #cd /moxa/mxser/utility/term /*
5 #. /nsterm
6          Communication Setup /dev/ttySO /dev/ttyMO
7          Dumb Terminal
8 Li nux
9          Advaced Transfer Modes Send Pattern
10

```

